







ADXL345

SCL
SDA
SDO
INT2
INT1
CS
VCC
GND

ARDUINO

MICRO

ATmega328P

5V

GND

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

